

CIMPULSE™ 51MP

High Performance Metalworking Fluid



Product Information Flyer

APPLICATION

CIMPULSE 51MP is a multi-purpose, heavy-duty fluid for machining and grinding. It offers high performance without the use of traditional extreme pressure lubricants and is recommended for turning, drilling, milling, reaming, boring, tapping, broaching, sawing and grinding for most metals other than magnesium alloys or cast aluminum.

FEATURES & BENEFITS

- For all metals and all operations (see above)
- For use in a wide range of water qualities
- Excellent foam control in soft water and high pressure applications
- Does not contain DCHA or Triazine
- Machines stay clean and parts are easy to wash

RECOMMENDED STARTING DILUTIONS:

CIMPULSE 51MP is to be mixed with water for use. Always add concentrate to water. Fluid may be more difficult to mix when water temperature is cold. Add no materials to the concentrate or mix unless approved by CIMCOOL®.

Machining and Grinding: 5% to 15% (1:19 to 1:6)

CONCENTRATION:

The Refractometer Factor is 1.0

TYPICAL PHYSICAL AND CHEMICAL PROPERTIES:

Physical State: Liquid Appearance and Odor: Cloudy/Chemical Solubility in water: 100% miscible Weight, lb./gal, 60°F (15.6°C): 8.2

Viscosity (SUS) @ 100°F (37.8°C): 700 Flash Point: SEE MSDS pH Concentrate: 10.1 Flash Point: SEE MSDS pH Mix 5%, Typical: 9.0

Sulfur, wt%: <0.02 Chlorine/Chloride, wt%: 0.0/<50ppm

Siloxanes: Yes (Paintable)

HANDLING and STORAGE:

If frozen, thaw completely at room temperature. Inside storage is recommended.

SAFETY DATA SHEET:

Available at www.cimcool.com

For additional information refer to its OSHA MSDS, website or contact your local CIMCOOL TECHNICAL SPECIALIST OR DISTRICT MANAGER, or you may contact CIMCOOL® Technical Services at 1-513-458-8199.

Limitation of Liability: Under no circumstances, shall we or any affiliate of ours have any liability whatsoever for loss of use, or for any indirect or consequential damages. Minor formulation changes or normal variations in the manufacture of this product may cause slight variances in the data presented on this sheet.